


WG24 PTO STUMP GRINDER



OPERATOR'S MANUAL



DISCOVER THE WOODLAND™



TABLE OF CONTENTS

TABLE OF CONTENTS	1
INTRODUCTION	3
INTENDED USE	4
TECHNICAL SPECIFICATIONS	4
TOOLS REQUIRED	4
OVERALL DIMENSIONS	5
3-POINT HITCH DIMENSIONS	6
GENERAL SAFETY RULES	7
PERSONAL SAFETY	8
MACHINE USE AND CARE	9
COMPONENT LISTS	10
TO-SCALE HARDWARE	11
BOLTS & SCREWS	11
WASHERS	12
NUTS	12
ASSEMBLY	13
1. UNPACKING	13
2. TOP LINK BRACKET	15
3. DEFLECTOR	16
4. CHAINSAW HOLDER	17
5. MANUAL TUBE	18
SET-UP PROCEDURES	19
TRIMMING THE PTO SHAFT	19
PTO SHAFT CLUTCH RUN-IN	21
FLYWHEEL TOOTH TORQUING	23
TORQUE ADAPTER	24
OPERATION	26
PRE-START CHECKLIST	26
STARTUP	27
STUMP GRINDING PROCEDURE	30
INCORRECT GRINDING PROCEDURES	31
PULLING THROUGH THE CENTRE	31



GRINDING LEFT-TO-RIGHT	31
CHAINSAW HOLDER	32
STORAGE	32
MAINTENANCE	33
REPLACING TEETH	33
GREASING	34
REPLACEMENT PARTS ORDERING	36
EXPLODED ASSEMBLY VIEWS	37
COMPLETE ASSEMBLY	37
PTO SHAFT	38
PARTS LIST	39
NOTES	41



INTRODUCTION

Congratulations on your purchase and welcome to Woodland Mills! This manual gives you the necessary information about your machine so you will be able to use it properly. The entire manual must be read and understood before you start using the machine. If any questions should arise that are not covered by this manual, please contact Woodland Mills Inc.

OWNER'S RECORD

Please take a moment to record the following information about your stump grinder. If you need to call for assistance, please be ready to provide your model and serial numbers. This information will allow us to help you more quickly when you call.

MODEL NUMBER

SERIAL NUMBER

DATE OF PURCHASE

This machine is designed for certain applications only. We strongly recommend that this machine not be modified and/or used for any application other than that for which it was designed. If you have any questions relative to a particular application, DO NOT use the machine until you have first contacted us to determine if it can or should be performed with the product.

For technical questions and replacement parts, please contact Woodland Mills Inc.



INTENDED USE

This stump grinder is designed for grinding stumps using a tractor's Power Take-Off (PTO) at an operating rpm of 540.

TECHNICAL SPECIFICATIONS

Item	Specification
Recommended Horsepower	15 - 45 hp
Flywheel Diameter	24 in [610 mm]
Number of Teeth	34
Tooth	Grade 8.8 Carbide Steel, Bolt-in
Tooth Torque Specification	160 ft•lb [215 N•m]
Required PTO Speed	540 rpm
Maximum Cutting Depth Per Pass	5 in [127 mm]
Maximum Depth Below Grade	6 in [152 mm]
Shipping Weight	470 lb [213 kg]

TOOLS REQUIRED




Tool	Specification	Use
Phillips Head Screwdriver	No. 3	Assembly
Wrench/Socket	13 mm (2X)	Assembly
Wrench/Socket	16 mm (2X)	PTO Clutch Run-In
Wrench/Socket	17 mm	PTO Clutch Lock Pin
Wrench/Socket	24 mm	Tooth Replacement
Torque Wrench	Capable of 160 ft•lb [215 N•m]	Multiple
Calliper*	Vernier, Dial, or Digital	PTO Clutch Run-In
Hacksaw**		PTO Trimming
Coloured Pencil/Marker		PTO Clutch Run-In

* Recommended but not required.

** Only if PTO shaft requires trimming. See [*Trimming the PTO Shaft*](#) section for more detail.






OVERALL DIMENSIONS





3-POINT HITCH DIMENSIONS





GENERAL SAFETY RULES



WARNING!

Read and understand all instructions. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.



WARNING!

The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product but must be supplied by the operator.

- All Federal and State laws and any regulation having jurisdiction covering the safety requirements for use of the machine take precedence over the statements in this manual. Users of this machine must adhere to such regulations.
- Only people that have read and understood these instructions are permitted to use the stump grinder.
- Inspect the stump grinder and tractor at the beginning of every working day and repair any defects.
- Stop the engine and make sure that the machine will not start accidentally while repairing defects or performing maintenance.
- Do not disable or remove the stump grinder's safety devices.
- Always locate and mark buried wires, cables, and pipelines prior to grinding.



PERSONAL SAFETY

- **Stay alert**, watch what you are doing and use common sense when operating machinery. Do not use a machine when you are tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating machinery may result in serious personal injury.
- **Dress properly.** Do not wear loose clothing, dangling objects, or jewelry. Keep your hair, clothing, and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts. Air vents often cover moving parts and should be avoided.
- **Use safety apparel and equipment.** Use safety goggles or safety glasses with side shields which comply with current national standards, or when needed, a face shield. Use a dust mask in dusty work conditions. This applies to all persons in the work area. Also use non-skid safety shoes, hardhat, gloves, dust collection systems, and hearing protection when appropriate.
- **Do not overreach.** Keep proper footing and balance at all times.
- **Remove adjusting keys or wrenches** before connecting to the power supply or turning on the machine. A wrench or key that is left attached to a rotating part of the machine may result in personal injury.
- **Never conduct any maintenance or make any other adjustments while the tractor engine is running.** Always shut the tractor engine off, remove the ignition key, and keep the engine off before carrying out any of the following procedures. Consult your tractor's operator manual for safe shutdown procedures to prevent accidental ignition.
- **Never** allow passengers to ride on the stump grinder.







MACHINE USE AND CARE


- **Always be sure the operator is familiar** with proper safety precautions and operation techniques before using machine.
- **Do not force the machine.** Machines do a better and safer job when used in the manner for which they are designed.
- **Storing the machine.** When the machine is not in use, store it in a dry, secure place or keep it well-covered and out of the reach of children. Inspect the machine for good working condition prior to storage and before each use.
- **Maintain the machine.** It is recommended that the general condition of the machine be examined before it is used. Keep your machine in good working order by adopting a program of conscientious repair and maintenance in accordance with the recommended procedures found in this manual. If any abnormal vibrations or noise occurs, turn the machine off immediately and have the problem corrected before further use.
- **Cleaning.** Use a pressure washer to clean the carbide teeth while taking care not to pressure-wash the bearings as this could introduce water into areas of the machine that may cause malfunction or damage.
- **Use only accessories that are recommended** by the manufacturer. Accessories that may be suitable for another machine may create a risk of injury when used on this machine.
- **Always** operate the machine with all safety devices and guards in place and in good working order. DO NOT modify or make changes to safety devices. DO NOT operate the machine if any safety devices or guards are missing or inoperative.
- **Never leave the machine running unattended.**
- **Never use the machine to grind anything other than stumps** or for any purpose other than grinding stumps as described in this manual.



COMPONENT LISTS

Verify all component and hardware quantities are correct prior to assembling the stump grinder.

1x	Deflector Plate [0001230]	
1x	Chainsaw Holder Assembly	
1x	Manual Tube [0001655]	
1x	PTO Shaft (North America) [0001239]	

1x	PTO Shaft (Europe) [0004135]	
----	--	---





Components in **RED** are specific to European stump grinders



TO-SCALE HARDWARE

BOLTS & SCREWS

Hardware graphics are printed at 1:1 scale for ease of identification. Simply place the hardware over the image in the tables to verify it is the correct size.

3x	HHB-MBJ080FCJ	M8 X 1.25 X 25 mm HEX BOLT
		
2x	HHB-MBM085FCJ	M10 X 1.5 X 30 mm HEX BOLT
		
4x	HHB-MBR090FCJ	M12 X 1.75 X 35 mm HEX BOLT
		
2x	PPH-MBA075FCE	M5 X 0.8 X 20 mm PHILLIPS PAN HEAD SCREW
		

SCALES

Ruler scales are also provided below to double-check bolt and screw lengths when necessary.








CENTIMETRES / MILLIMETRES






INCHES

WASHERS

2x	FTW-MBA000AJ M5 FLAT WASHER	3x	FTW-MBJ000AJ M8 FLAT WASHER
			
4x	FTW-MBM000AJ M10 FLAT WASHER	8x	FTW-MBR000AJ M12 FLAT WASHER
			
2x	SLW-MBAAJ M5 SPLIT LOCK WASHER		
			


NUTS

3x	HLN-MBJCH M8 X 1.25 LOCK NUT	2x	HLN-MBMCH M10 X 1.5 LOCK NUT
			
4x	HLN-MBRCH M12 X 1.75 LOCK NUT		
			


ASSEMBLY

1. UNPACKING


Unfasten the M8 X 25 mm hex bolts from the four (4) bottom corners of the crate and remove the top frame.




Unfasten the two (2) M8 X 25 mm hex bolts securing both support legs to the bottom crate frame.



The top link bracket is installed upside-down due to shipping space constraints.






Loosen the nut on the front side of the back frame just enough so the top link bracket can be rotated 180° for the next assembly step.




2. TOP LINK BRACKET

Using the hardware listed below, assemble the top link bracket to the back frame as shown.





4x	M12 X 35 mm Hex Bolt		8x	M12 Flat Washer	
4x	M12 Lock Nut				


Orient the top link bracket so that it is rotated 180° from how it was shipped in the previous step. The hitch pin must be on *top*. Secure it to the back frame using four (4) M12 X 35 mm hex bolts, M12 flat washers, and M12 lock nuts.



3. DEFLECTOR

Using the hardware listed below, assemble the deflector to the flywheel housing as shown.






3x	M8 X 25 mm Hex Bolt		3x	M8 Flat Washer	
3x	M8 Lock Nut		1x	Deflector	






4. CHAINSAW HOLDER





Using the hardware listed below, assemble the chainsaw holder to the flywheel housing as shown.


2x	M10 X 30 mm Hex Bolt		4x	M10 Flat Washer	
2x	M10 Lock Nut	 	1x	Chainsaw Holder	



5. MANUAL TUBE

Using the hardware listed below, assemble the manual tube to the back frame as shown. Remove the cap from the manual tube to gain access to the centre mounting hole.

2x	M5 X 20 mm Phillips Pan Head Screw		2x	M5 Flat Washer	
2x	M5 Split Lock Washer		1x	Manual Tube	




SET-UP PROCEDURES

TRIMMING THE PTO SHAFT


The stump grinder is shipped with a slip clutch PTO shaft that can be fitted to most Category 1 tractors. The PTO shaft may need to be trimmed depending on your tractor and configuration. Follow the steps below to ensure the PTO shaft is correctly fitted to your tractor.

****Note: the slip clutch end of the PTO shaft mounts to the stump grinder.****

1. Attach the stump grinder to the tractor's 3-point hitch system. Do not install the PTO shaft.
2. Raise the stump grinder so that the shaft on the tractor is in line with the shaft on the stump grinder.
3. Measure the distance between the locking grooves on the splined shafts of the tractor and stump grinder (**Dim A**) as shown below:




4. Verify the distance between the locking pins on the PTO shaft while in the compressed state (**Dim B**) as shown in the image below. It should measure 34" (862.5 mm).



5. If **Dim A** is at least 1" (25 mm) longer than **Dim B**, the PTO shaft does not require trimming. It is recommended the shaft not be used if there is less than 6" (150 mm) of overlap between the two halves of the PTO shaft when the equipment is in the operating position.
6. If **Dim B** is longer than **Dim A**, the PTO shaft will require trimming. Use this equation to calculate the correct amount to trim:

$$(B - A) + 1 \text{ inch} = C \text{ (Amount to Trim)}$$

7. Once **C** has been calculated, trim that amount from **BOTH** halves of the PTO shaft safety cover *first*, then trim the same amount from both shafts. This will ensure the safety cover on each end remains a few inches back from the ends of the shafts, otherwise PTO shaft reassembly could be difficult.
8. After trimming both halves of the PTO shaft, use a file to remove any burrs or sharp edges and slide the halves back together, ensuring they telescope in-and-out freely. The PTO shaft is now ready to connect the stump grinder to the tractor for operation.




PTO SHAFT CLUTCH RUN-IN

The stump grinder is shipped with a slip clutch PTO shaft. Follow the steps below before using your stump grinder to ensure the PTO shaft clutch plates are set properly.

****This procedure should be performed periodically during ownership as the clutch plates can stick together, particularly after long periods of inactivity. This can prevent the plates from slipping during operation as designed, resulting in high loads and possible damage to the steel shaft, which is not covered under warranty.****

1. Connect the PTO shaft to the stump grinder and tractor with the clutch end of the PTO shaft mounted to the stump grinder. Insert the locking pin on the clutch yoke and tighten the nut using a wrench/socket.
2. Using a coloured pencil or marker, scribe a line across the exposed edges of the clutch plates.
3. Using a wrench/socket, loosen all 8 spring tension nuts uniformly until the ends of the nuts are flush with the ends of the bolts (**Fig. A**).






4. Start the tractor and engage the PTO for 2-3 seconds to permit slippage of clutch surfaces. Disengage the PTO then re-engage a second time for 2-3 seconds. Disengage the PTO again, shut off the tractor, and remove the key. Wait for all components to stop rotating before removing the PTO shaft from tractor.
5. Inspect the clutch and ensure that the scribed markings made across the clutch plates have changed position. Slippage has not occurred if the two marks on the clutch plates are still aligned. A clutch that has not slipped must be disassembled to separate the clutch plates.
6. Tighten all 8 nuts until the proper spring height dimension values are achieved per the “**PTO Shaft Clutch Spring Height vs. Horsepower**” table for your PTO output horsepower. It is recommended that a calliper (either digital, dial, or vernier—similar to the one shown below) be used to accurately verify the spring height measurements. After setting all 8 spring heights, the clutch is now ready for use.

PTO Shaft Clutch Spring Height vs. Horsepower

PTO Shaft	Clutch Flange Dia	PTO hp	Spring Height
5S.FF2	7- $\frac{5}{8}$ " (200 mm)	15-20 hp	1.26" (31.9 mm)
		25 hp	1.25" (31.7 mm)
		30 hp	1.24" (31.4 mm)
		35 hp	1.22" (31.1 mm)
		45 hp	1.20" (30.5 mm)

All ratings are at 540 rpm PTO speed




Typical vernier calliper

7. The clutch should be checked during the first hour of use and periodically each week thereafter. Excessive clutch plate slippage, burning odour, or visible smoking should not be observed during use.



FLYWHEEL TOOTH TORQUING


Prior to each operation, ensure all 34 teeth are torqued to 160 ft•lb (215 N•m) using a torque wrench with a 24 mm socket.






TORQUE ADAPTER



The stump grinder ships with a 24 mm torque adapter to assist torquing the four (4) outward-pointing teeth. It connects directly to a $\frac{1}{2}$ in drive torque wrench. Use a $\frac{3}{8}$ -to- $\frac{1}{2}$ in socket adapter if the torque wrench is $\frac{3}{8}$ in drive.



It is critical that the torque adapter be positioned 90° to the torque wrench when torquing the nuts (✓). If left straight (✗), the nuts will be over-torqued and likely damage the grinder teeth threads.



Slide the torque adapter and torque wrench over the nut and torque the nut by rotating it clockwise. Repeat the process for all four (4) of the outward-pointing teeth. Ensure the torque adapter remains 90° to the torque wrench throughout the entire process.





OPERATION

PRE-START CHECKLIST

1. Prior to operation, ensure all 34 teeth are torqued to 160 ft•lb [215 N•m] using a torque wrench with a 24 mm socket. Refer to the "**FLYWHEEL TOOTH TORQUING**" section of the operator's manual.
2. With the stump grinder attached to your tractor, take the appropriate measurements to trim the PTO shaft. Refer to the "**TRIMMING THE PTO SHAFT**" section of the operator's manual for detailed instructions.

****Note: Failure to do so may result in severe damage to the implement and is not covered under warranty.****

3. Perform the clutch run-in procedure prior to using the stump grinder. Refer to the "**PTO SHAFT CLUTCH RUN-IN**" procedure in the operator's manual.
4. The stump grinder has multiple bearings fitted with Zerk fittings for greasing. The PTO shaft is fitted with two (2) Zerk fittings, one on each yoke. The PTO shaft and all bearings come pre-greased and do not require greasing on initial start up. Refer to the "**MAINTENANCE**" section of the operator's manual for detailed maintenance instructions.
5. Read the "**STUMP GRINDING PROCEDURE**" section of the operator's manual before operating the stump grinder. It is important to grind stumps correctly to ensure optimal grinding performance and safe operation.


STARTUP




WARNING!

To avoid death or serious injury, do not grind stumps containing embedded foreign objects such as nails, wire, metal fragments, etc.


1. Wear heavy-duty work gloves, ANSI-approved goggles behind a full face shield, steel-toed work boots, and a dust mask.
2. Securely attach the stump grinder to the tractor's 3-point hitch system and install the PTO shaft.
3. Prior to each daily use, check all 34 teeth and ensure they are not loose, missing, or damaged, and are torqued to the proper specification. Torque any undamaged loose teeth to 160 ft•lb (215 N•m) using a torque wrench with a 24 mm socket.



4. Remove the stabilizer pin prior to operation as shown below:




5. Remove the leg locking pins, slide the legs up inside the tubes, and reinstall the locking pins to secure them in place.




6. Reverse over a tree stump and lower the stump grinder so it will remove 2" (50 mm) per pass. Always ensure the grinder is cutting properly and not jumping around erratically.

7. Once the stump is at ground level, continue to take up to 2" (50 mm) deep passes until the stump and roots are 4-6" (100-150 mm) below grade. Keep a watch out for foreign objects below the soil like rocks or buried metal. These can damage or break the teeth resulting in poor grinding performance.
8. During use, it is important to never let the stump grinder sway beyond an angle that will allow the PTO shaft to separate. Do not operate the stump grinder with less than 6" (150 mm) of overlap between the two halves of the PTO shaft. If the stump grinder begins to sway, it means either the tractor is advancing faster than the grinder can remove material or that too much material is being removed per pass. If this is observed, immediately stop moving forward and position the tractor and stump grinder in a manner so that it is in the vertical position. Take a slower pass and/or shallower cut if necessary.




STUMP GRINDING PROCEDURE

The flywheel spins clockwise (when facing the rear of the machine) with the effective cutting area in the lower-left quadrant as shown below:




When grinding a tree stump, always start from the right side of the stump, moving incrementally to the left, pulling the grinder straight forward through the stump on each pass. When grinding softwoods like pine, spruce, or poplar, it may be permissible to remove upwards of 2" (50 mm) of material per pass. However, hardwoods like oak, ash, and birch can be much more dense and the depth of grind may only be up to 1" (25 mm). If the chassis is swaying like described in the **previous section**, or the grinder is vibrating or bouncing, reduce the depth of cut or feed rate accordingly.




INCORRECT GRINDING PROCEDURES

It is critical that the stump grinder is never pulled through the centre of a stump or ground from left-to-right. This will induce severe vibration and cause the grinder to sway and bounce. It may also damage the machine and/or break teeth. Follow the directions on the ***previous page*** to ensure efficient and safe grinding.

PULLING THROUGH THE CENTRE




GRINDING LEFT-TO-RIGHT





CHAINSAW HOLDER

Use the chainsaw holder only during transport. Always remove the chainsaw from the holder prior to grinding stumps.



STORAGE

1. Lower both support legs and reinsert the locking pins.
2. Insert the stabilizer pin in either the left or right side of machine. It does not matter which side is selected.
3. Lower the stump grinder onto a flat, level surface.
4. Disconnect the PTO shaft.
5. Remove the stump grinder from the tractor's 3-point hitch system.




MAINTENANCE

- Proper routine maintenance is critical to operator safety, achieving proper stump grinding results, and prolonging the life of the machine.
- Before cleaning and/or any maintenance is performed on the stump grinder, always turn off the tractor engine and disconnect the PTO shaft.
- Inspect the machine before each use for loose nuts and worn cutting teeth and clean any debris that has built-up.
- After 2 hours of operation, check for loose nuts and worn cutting teeth. Tighten and replace as necessary.
- Grease the bearings and the pivot pins on the main housing as needed before each use. Do not over-grease the bearings as this can blow out the seals and cause premature bearing failure. Refer to section, **GREASING**, for information.
- Inspect the clutch plates on the PTO shaft periodically to ensure that they are not seized together. Refer to **PTO SHAFT CLUTCH RUN-IN** in the **SET UP PROCEDURES** section of the manual.

REPLACING TEETH

1. Disconnect the PTO shaft from the tractor and set the stump grinder on a flat, level surface.
2. Remove the M16 X 1.5 lock nut (fine thread) from the back of the tooth using a 24 mm wrench or socket.
3. Remove the worn cutting tooth while noting its orientation so that the replacement tooth will be installed in the same manner.



4. Install the replacement tooth and lock nut using a torque wrench set to 160 ft•lb (215 N•m). Refer to section **FLYWHEEL TOOTH TORQUING** for more detail.


GREASING

The stump grinder has six (6) grease points: two (2) flywheel bearings, two (2) hinge pins, and two (2) on the PTO shaft. Check each grease point prior to use and add grease as needed.


*****Warning: These grease points come pre-greased from the factory. Do not add grease to these points on a new stump grinder. Over-greasing can damage the bearing seals.*****




Flywheel Shaft Bearings (Underside of Flywheel Housing)




Right Pivot Hinge



Left Pivot Hinge




PTO Shaft: Slip Clutch End



PTO Shaft: Tractor End

REPLACEMENT PARTS ORDERING

When ordering replacement parts, first locate the balloon number(s) from the appropriate **exploded assembly view** as shown in the example below:



Next, turn to the **Parts List** section and locate the balloon number in the “**Item**” column:

PARTS LIST


Item	Quantity		Part No.	Description
	14 hp	9.5 hp		
1	4	4	0001073	TRACK RAIL, 58.5 mm TALL
2	2	2	0001075	LOG BUNK, END
3	2	2	0001080	LOG BUNK, MID
4	1	1	0001084	LOG BUNK, CENTER
5	2	2	0001072	REINFORCEMENT PLATE, 90 X 200 mm
6	12	12	0001071	LEVELLING FOOT BASE
7	4	4	0001055	CARRIAGE STOP
8	1	1	0001062	LOG CLAMP SHAFT AND BRACKET WELDMENT

Record the part number (e.g. 0001071, HHB-MBM080FCJ, etc.) in the “**Part No.**” column.

Contact Woodland Mills through the website or via phone/email. If possible, include the invoice or sales number from the purchased product so an associated account can be located. If the account has multiple addresses on file, please indicate to which address the replacement part(s) will be shipped.




EXPLODED ASSEMBLY VIEWS COMPLETE ASSEMBLY





PTO SHAFT



Item **25.3 [Retaining Clip Kit]** is included with Item **25.2 [Cover/Retaining Clip Kit]**. Order 25.2 if covers are needed as clips are automatically included. Order 25.3 if only clips are needed.



PARTS LIST

NA = North America | **EU** = Europe

Highlighted row(s) indicate components exclusive to European markets.

Item	Quantity		Part No.	Description
	NA	EU		
1	1	1	0001229	FLYWHEEL HOUSING
2	1	1	0006478	BACK FRAME
3	1	1	0006479	TOP LINK BRACKET
4	2	2	0001228	BACK SUPPORT LEG
5	1	1	0001231	FLYWHEEL
6	1	1	0001233	FLYWHEEL SHAFT
7	34	34	0001232	FLYWHEEL TOOTH
8	2	2	0001238	GREASE PIN, 25 mm DIA
9	2	2	0004707	GREASE FITTING, STRAIGHT, M6 X 1 TAPERED THD
10	1	1	0001230	DEFLECTOR PLATE
11	1	1	0001234	CHAINSAW HOLDER MOUNTING PLATE
12	1	1	0001235	CHAINSAW HOLDER CLAMPING PLATE
13	2	2	0001236	CHAINSAW HOLDER RUBBER MAT
14	1	1	0001237	CHAINSAW REST RUBBER MAT
15	1	1	0001751	KNOB, MULTI-LOBE, 50 mm OD, M10 X 1.5, 40 mm LG
16	2	2	0002699	SPACER, 11 ID X 21 OD X 11 mm LG
17	1	1	0001156	3-POINT HITCH PIN, UPPER, 19 mm DIA, 90 mm USEABLE LG
18	2	2	0001240	LOWER 3-POINT HITCH PIN, 21 mm DIA X 135 mm LG
19	1	1	0001750	LOCKING PIN, 19 mm DIA X 150 mm LG
20	2	2	0004704	LOCKING PIN, SQUARE, 10 mm DIA, 70 mm USABLE LG, 87 mm LG
21	3	3	0004705	LINCH PIN, 10 mm DIA, 38 mm USABLE LG, 45 mm LG
22	1	1	0004706	COTTER PIN, HAIRPIN, 16-20 mm CLEVIS, 4 mm WIRE DIA
23	1	1	0001655	MANUAL TUBE
24	1	1	0004194	TORQUE ADAPTER, 1/2 in DRIVE, 12-POINT 24 mm
25	1	-	0001239	PTO SHAFT W/ CLUTCH, TRIMMABLE, 36-44 in [914-1121 mm]
	-	1	0004135	PTO SHAFT W/ CLUTCH, TRIMMABLE, 38-46 in [965-1168 mm], EU
25.1	1	1	0002572	PTO SHAFT CLUTCH DISC KIT
25.2	1	-	0003049	COVER/RETAINING CLIP KIT
	-	1	0003059	COVER/RETAINING CLIP KIT, EU
25.3	1	1	0003058	RETAINING CLIP KIT
25.4	1	1	0003056	LOCKING PIN KIT
26	1	1	0006495	LABEL, SERIAL NUMBER
27	2	2	UCF210	FLANGE BEARING, SQ, 4-BOLT, 50 mm SFT, 111 mm C-C
28	5	5	HHB-MBJ080FCJ	HEX HEAD BOLT, CLS 8.8, M8 X 1.25, 25 mm LG, FULL
29	2	2	HHB-MBM085FCJ	HEX HEAD BOLT, CLS 8.8, M10 X 1.5, 30 mm LG, FULL
30	2	2	HHB-MBM100FCJ	HEX HEAD BOLT, CLS 8.8, M10 X 1.5, 45 mm LG, FULL
31	4	4	HHB-MBR090FCJ	HEX HEAD BOLT, CLS 8.8, M12 X 1.75, 35 mm LG, FULL
32	8	8	HHB-MBR100FCJ	HEX HEAD BOLT, CLS 8.8, M12 X 1.75, 45 mm LG, FULL
33	1	1	SNC-MBR165PCJ	CARRIAGE BOLT, SQ NECK, CLS 8.8, M12 X 1.75, 110 mm LG, 30 mm LG THD
34	2	2	PPH-MBA075FCE	SCREW, PPH, CLS 4.8, M5 X 0.8, 20 mm LG, FULL



Item	Quantity		Part No.	Description
	NA	EU		
35	4	4	SHC-MCA115FCP	SHCS, CLS 12.9, M16 X 2, 60 mm LG, FULL
36	2	2	FTW-MBA000AJ	FLAT WASHER, M5
37	3	3	FTW-MBJ000AJ	FLAT WASHER, M8
38	8	8	FTW-MBM000AJ	FLAT WASHER, M10
39	17	17	FTW-MBR000AJ	FLAT WASHER, M12
40	4	4	FTW-MCA000AJ	FLAT WASHER, M16
41	2	2	SLW-MBAAJ	SPLIT LOCK WASHER, M5
42	5	5	HLN-MBJCH	LOCK NUT, CLS 8, M8 X 1.25
43	4	4	HLN-MBMCH	LOCK NUT, CLS 8, M10 X 1.5
44	13	13	HLN-MBRCH	LOCK NUT, CLS 8, M12 X 1.75
45	34	34	HLN-MCBCH	LOCK NUT, CLS 8, M16 X 1.5
46	4	4	HLN-MCACH	LOCK NUT, CLS 8, M16 X 2

[illegible]



Lined area for notes or additional information, consisting of multiple horizontal lines.



Lined area for notes or additional information, consisting of 25 horizontal lines.



Lined area for notes or additional information, consisting of multiple horizontal lines.



DISCOVER THE WOODLAND™